

# **N•INC**

## **TELEPHONE Instruction Manual**



### **KX-T076CID**

**Please read this manual before use**

Thank you for purchasing our products, before use, please read this manual carefully, and keep, to prepare for possible period of want or need.

## **Function Introduction**

FSK/DTMF incoming caller ID display, automatic identification

Maximum 30 groups 12 digits incoming call.

Maximum 10 groups 12 digits outgoing call.

Number/Time check of calling number, fast up/down check and redial.

Music on Hold.

Light indicator in use.

### **1. The function key description**

Keep / bell button: functional off-hook state reserved for music, LCD display "HoLD"; the on-hook state for function select ring type, LCD display "riNg 01", continuous press this button to 24 ringtone loop, or with the page up down buttons to set the;

Keys: the hook into the menu settings, LCD display "Set 1 dAtE"; a dial to exit function;

Redial / pause: query and electricity press this button dial this number, press two to add 0 dial this number; for the suspension of input predictive dialer, display "P".

The delete key brightness /: predictive dialer, check the state, delete function; to return the function menu settings, set up the state menu item for exit function; in search of state, press the button 3 seconds can delete all the incoming or outgoing number; in the standby mode by the key to enter the brightness regulation function, LCD display "LCd 3", continuous press this key to cycle 5 level adjustment, the default level third.

To search key: press this key on-hook or off-hook to go electric information query function;

On-hook or off-hook over key: press this key to enter the call information query, caller ID record information the first time, continuous press this key is displayed in turn call log information to the current time. The ring settings and menu settings for the corresponding numbers over choice functions, and time settings.

Under the double bond: on-hook or off-hook press this key to enter the call information query, display the current time of the call record information,

continuous press this key is orderly display call log information to the earliest time. The ring settings and menu settings for the corresponding numbers down option, minus function for time time settings.

## **2. Manual setting:**

Setting method of switching functions

P/T hang long press "\*" button for 3 seconds and audio dialing (default) / pulse dial Anti-theft hang long press "#" button for 3 seconds (default) / no anti-theft alarm

Hang long press the \* key, display "PUSLE", as the pulse dialing; display "tONE", to the tone dialing. Cycle can be set.

Hang long press # button, display "PPP ON", as the theft; display "PPP OFF", as the security clearance. Cycle can be set

## **3. Menu settings**

On-hook state press set key, enter the set state, LCD display "Set 1 DATE", at the same time, with the page up down keys to select settings, LCD also display settings corresponding. Then press set button to enter the settings. After a set is complete, press set button to confirm, the next one is set. The delete button to return to the previous setting state by setting. Setting press exit directly from the standby state.

The specific setting items are as follows:

The date and time

Set the LCD prompt "SEt 1 DAte", press set button to confirm. Enter the date / time settings, followed by the year, month, day, hour, minute set.

If the set "09" flashes in the display, page up down button to modify, press set button to confirm to enter the month to set, modify the method and set the same year, and then set the key to in turn modify the days, hours and minutes. The hours and minutes set consists of ten and a bit were set. Press the set button to confirm. Minutes when the bit is set, then the opportunity to automatically clear seconds.

The use of FSK calls can automatically refresh the current date and time, DTMF call does not refresh the current date and time. Year to set.

The 5 local code

Set the LCD prompt "SEt 2 COde", press set button to confirm, LCD will display "COde --", press set button to confirm, into the local area code set, then directly on the number keys enter the local code, press the delete key delete input number, then press set button to confirm. Such as "COde - 0755",

said the local code is 0755.

Use the call does not display and set matching local codes, such as local code for 0755, call 075512345678, only "12345678".

The 2 outgoing code

Set the LCD prompt "SEt 3 PCODE", press set button to confirm, LCD will display "PCODE", press set button to confirm, enter the code set out, this time directly on the number keys input, press the delete key delete input number, then press set button to confirm. If the display "PCODE -9", said the exit code for 9.

The use of such as set out yards, set aside or query call more than 5 number to dial out, will automatically dial out code before the number.

The alarm settings:

Set the LCD will prompt "SEt 4 ALERt", press set button to enter the show, "00-00 OFF". The first 4 set specific ring time, right into the alarm switch state, show "ON" for "OFF", show off.

If you set the alarm clock function using start on time, it will alarm for 1 minutes, press any key to cancel the alarm. If the alarm when the fork (HKS high), hang a seconds after off-hook. As is scheduled to arrive at the alarm time, the telephone is off-hook, bell, missed calls (ringing stops in 6S), \ the alarm will automatically be cancelled.

#### **4. To electric information query**

On-hook or off-hook press to enter to enquiries function of electric information query, display recently dialed number information, press to electric query keys in order to forward queries to multiple groups have electric information. The query LCD light to electrical signs, display the current number and call time length, and the group number in the record to electric information number. If the number of digits to power more than LCD display, number of screen display, display number to a "-" prompt, at this point is to press again to electric query key until after that, in order to enter the next group display. It can grow fast query according to electric query key. Enter the query state press up key down key can move forward or backward query information. After looking up, LCD display "---EnD---". Go electric number the longest recorded 32.

#### **5. The incoming information query**

On-hook or off-hook can also according to page up down key to enter the call query function, the key is to recent earliest direction query, double bond is the first call to the nearest telephone inquiries, the other key functions consistent

with inquiries. Finish the LCD show "---EnD---". The phone number the longest recorded 16.

## **6. Music on hold**

Off-hook state, according to retain key to enter the music keep state, while retaining the music sounded, you can put down the handle

And then to pick up the phone, keep the music stops, automatically enters the handle call state.

**Redial function**

Picking up the redial button, then the opportunity to automatically dial out last dial telephone. In search of calls, to power again when the redial button, the phone will be the displayed phone numbers.

**Dial telephone**

Handle, dial a phone number to dial, dial to call, the call is completed hung up the receiver.

**Answer the phone**

The phone rang, file handle can call, the call is completed hung up the receiver.